

www.gemtor.com

# **High Visibility Fall Protection Vest**

Gemtor's Fall Protection Vest is the perfect choice for improved worker safety while wearing a harness in an environment where high visibility is desired. Designed for comfort and ease of use, the harness/vest combo is ideal for busy locations where worker safety and sight recognition are required.

This vest is ANSI/ISEA 107-2015 Type R, Class 2 compliant. It provides high visibility in bright and low light conditions by incorporating extremely bright fabric with reflective trim.

The vest has a mesh liner that encapsulates yet allows inspection of the harness straps. This prevents inadvertent twisting of the straps and allows for ease of putting on and taking off the vest. A zipper located at the lower rear edge retains the leg straps when the vest is not being used for fall protection and provides access to the harness for inspection and cleaning purposes. Hand pockets are provided in the area near each hip and lined with a solid nylon fabric for duarability.

The Fall Protection Vest is designed as part of a system that includes a specially configured energy absorber lanyard (Model # SPCL) that fits in a pocket located at the center of the back. The right shoulder has a retaining strap with a snap to hold the lanyard webbing neatly over the shoulder. Double layer front pockets hold the lanyards excess webbing and snaphook in one layer when not in use. The outter layer can be used to hold the wearer's gear. The Vest may also be used with a variety of standard energy absorbers, self-retracting lifelines and lanyards, and other lanyards and lifelines.

### **Features**

- Bright Yellow, 100% Polyester mesh shell and liner.
- Heavy duty Nylon zipper for front closure.
- ANSI/ISEA 107-2015 Type R, Class 2 compliant retro-reflective strips.
- Nylon edging around sleeve and neck openings.
- Zipper access at bottom for retention of leg straps when not in use. The zipper also allows access for inspection and cleaning purposes.
- Lightweight and comfortable.
- OSHA/ANSI/CSA compliant full body harness
- Standard dorsal (back) D-ring for fall arrest or restraint.
- Available front D-ring for rescue positioning restraint or climbing
- Optional hip D-rings for positioning or restraint.
- Pass-thru chest strap buckle
- Available with pass-thru or tongue buckle leg straps.
- Meets OSHA, ANSI Z359.11, ANSI A10.32, ANSI/ISEA 107-2004 Class 2.



### Available Models/Sizes

#### Pass-Thru Buckles

846427-1 - Pass-thru legs, Small

846427-2 - Pass-thru legs, Med

846427-3 - Pass-thru legs, Large

846427-4 - Pass-thru legs, XL

846427-9 - Pass-thru legs, 2XL

### Tongue Buckle Legs

FPV-TB-1-Tongue buckle legs, Small

FPV-TB-2-Tongue buckle legs, Med

FPV-TB-3-Tongue buckle legs, Large

FPV-TB-4 -Tongue buckle legs, XL

FPV-TB-9 -Tongue buckle legs, 2XL

# Pass-Thru Buckles & Front D-Ring

FPV-MFD-1 - Pass-thru legs, front D-ring, Small

FPV-MFD-2 - Pass-thru legs, front D-ring, Med

FPV-MFD-3 - Pass-thru legs, front D-ring, Large

FPV-MFD-4 - Pass-thru legs, front D-ring, XL

FPV-MFD-9 - Pass-thru legs, front D-ring, 2XL

# Tongue Buckle Legs & Front D-Ring

FPV-TBFD-1 - Tongue Buckle legs, front D-ring, Small

FPV-TBFD-2 - Tongue Buckle legs, front D-ring, Med

FPV-TBFD-3 - Tongue Buckle legs, front D-ring, Large

FPV-TBFD-4 - Tongue Buckle legs, front D-ring, XL

FPV-TBFD-9 - Tongue Buckle legs, front D-ring, 2XL

Other Configurations Available

# **Complementary Components**

SPCL Lanyard - Adjustable length lanyad fits in a specially designed pocket at the center of the wearer's back. The lanyard features a steel carabiner and a forged steel snaphook, specify length.

SRD & SRL Series - Cable Self Retracting Devices - available in 10, 30, 50 & 65 ft lengths.

SRD Series Self-Retracting Device/Fall Limiter

With polyester web lifelines, available in various configurations in 6 or 11 ft. lengths.

### Usage, Inspection & Cleaning

The vest shall be routinely inspected according to prevailing conditions with a minimum of two (2) formal inspections by a competent person per year. Visual inspection is required before each use for mildew, wear, damage and other deterioration. Defective components shall be removed from service. Refer to documentation enclosed with the item for further detail.

Surface clean only with sponge or wet cloth using warm water and quality detergent. Do not use chlorine bleach or fabric softeners. Do not dry clean. Hang to dry.

Your Authorized Gemtor Distributor:



